



a place of mind
THE UNIVERSITY OF BRITISH COLUMBIA

Department of Risk Management Services
336 – 2389 Health Sciences Mall
Vancouver, BC V6T 1Z3

Telephone: 604 822 2029
Fax: 604 822 6650
www.riskmanagement.ubc.ca

**To: UBC Building Administrators
UBC Building Safety Committees**

**From: Guy Champagne
Asbestos Safety Coordinator
Risk Management Services
Date: September 15, 2015**

RE: Typical Use Asbestos

Historically, as asbestos only required minimal refining prior to its use in manufacturing, it was a very inexpensive and effective constituent of many products. One of the sectors that utilized asbestos most frequently was the construction industry.

Asbestos was added to building materials to give them strength and fire proofing. As a consequence, virtually all of the buildings constructed prior to 1980 contain some form of an asbestos building product.

The use of asbestos in most products was banned in the early 1970s but some manufacturers that produce products such as brake linings and clutch facings have found no other effective replacement for asbestos.

Asbestos Categories

Friable: products which contain asbestos that when dry, can easily be crumbled or powdered by hand. Examples of friable products are: mechanical insulation, sprayed insulation (fire resistant, acoustic, thermal, condensation control and decorative millboards).

Non-friable: products where the asbestos is bound in a tight matrix and will not easily shed asbestos fibres under normal day to day use. Examples of non-friable products are: roof shingles, asbestos cement pipes, caulking compounds, floor tiles, joint cements and welding rods.

Other products that may fall in either category, depending on their condition, are textiles and papers. Friable sprayed or trowelled asbestos insulating formulations applied for fire protection, thermal or acoustic insulation were used until late 1970's

Mechanical insulation was applied to pipes, boilers, etc. until the late 1970's. Acoustic or decorative finishes that were sprayed or trowelled in place were also applied until the late 1970's

Building Project	Friability	Dates of Use
Mechanical Insulation	high	1926 - mid 1970's
Spray Insulation	high	1935 - 1974
Texture Coat	moderate - high	1950 - mid 1970's
Floor Tile	low	1950 - late 1970's
Drywall Taping Compound	low - moderate	1945 - late 1970's
Cement Pipe	low	1935 - present
Brake Linings	low	1940 - present
Duct Wrap	moderate - high	1920 - mid 1970's
Textiles / Gaskets	low - moderate	1920 - present
Roofing Material	low	1920 - present
Ceiling Tiles (all removed from UBC building)	low - moderate	1950 - 1970's
Cement Board	low	1930 - present

If you have any further questions please contact me at 822-8772 or e-mail [Asbestos Safety Coordinator](#)